

Inhaltsverzeichnis

1. DXL - APRSmap englisch	26
2. Benutzer:OE2WAO	8
3. DXL - APRSmap	14
4. DXL - APRSmap Download	20
5. DXL - APRSmap operating	32

DXL - APRSmap englisch

[Versionsgeschichte interaktiv durchsuchen](#)
[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)

Zeile 34:

- **==First steps==**

[[Datei:Aprsmap-1st-start.jpg]]

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- *First of all you put in your callsign with **optinal** SSID

- *Second step is to choose your desired APRS icon

Zeile 34:

+ **==Operation manual and help==**

+ **[[DXL - APRSmap operating|>> Operating instructions]] - the help in handling the program**

+

+

+

[[Datei:Aprsmap-1st-start.jpg]]

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

+ *First of all you put in your callsign **(MY CALLSIGN)** with **optional** SSID

+ *Second step is to choose your desired APRS icon **(MY SYMBOL)**

<p>- *Next you will zoom to your QTH as far as you can 100% identify your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.</p>	<p>+ *Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.</p>
<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>	<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>
<p></p>	<p></p>
<p>Zeile 48:</p>	<p>Zeile 52:</p>
<p>austria.aprs2.net (APRS IS connection via Internet)</p>	<p>austria.aprs2.net (APRS IS connection via Internet)</p>
<p></p>	<p></p>
<p>- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS IS PASSCODE to find a possibility on getting your code.</p>	<p>+ *You also need to enter a valid APRS PASSCODE to transmit packets to the APR S network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.</p>
<p>- *Last but not least you have to activate CONNECT SERVER to get data from the network.</p>	<p>+ *Last but not least you have to activate CONNECT SERVER to get data from an to t he APRS network.</p>
<p></p>	<p></p>
<p>===Shortcuts===</p>	<p>===Shortcuts===</p>
<p>- : delete markers</p>	<p>+ <nowiki>:</nowiki> delete markers</p>
<p>@ reset <On Next Click> to menu mode</p>	<p>@ reset <On Next Click> to menu mode</p>
<p>a Animate (Click to Map to set Parameters)</p>	<p>a Animate (Click to Map to set Parameters)</p>
<p>Zeile 80:</p>	<p>Zeile 84:</p>
<p>M Compose Message</p>	<p>M Compose Message</p>
<p>R toggle Radiorange Map on/off</p>	<p>R toggle Radiorange Map on/off</p>
<p></p>	<p>+ T toggle Timestamp</p>
<p>S Screenshot bpm (win), png (linux)</p>	<p>S Screenshot bpm (win), png (linux)</p>
<p>W Rain map (use topo or dark map)</p>	<p>W Rain map (use topo or dark map)</p>


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	29
2 Installation	29
3 Operation manual and help	29
3.1 Shortcuts	30
4 Download	31
5 Further operation manual	31

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
austria.aprs2.net (APRS IS connection via Internet)

- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```

```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come

DXL - APRSmap englisch: Unterschied zwischen den Versionen

[Versionsgeschichte interaktiv durchsuchen](#)

[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)

Zeile 34:

– **==First steps==**

[[Datei:Aprsmap-1st-start.jpg]]

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

– *First of all you put in your callsign with **optional** SSID

– *Second step is to choose your desired APRS icon

Zeile 34:

+ **==Operation manual and help==**

+ **[[DXL - APRSmap operating|>> Operating instructions]] - the help in handling the program**

+

+

+

[[Datei:Aprsmap-1st-start.jpg]]

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

+ *First of all you put in your callsign **(MY CALLSIGN)** with **optional** SSID

+ *Second step is to choose your desired APRS icon **(MY SYMBOL)**

- *Next you will zoom to your QTH as far as you can 100% **identify** your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.

*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

Zeile 48:

austria.aprs2.net (APRS IS connection via Internet)

- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS **IS** PASSCODE to find a possibility on getting your code.

- *Last but not least you have to activate CONNECT SERVER to get data from the network.

===Shortcuts===

- : delete markers

@ reset <On Next Click> to menu mode

a Animate (Click to Map to set Parameters)

Zeile 80:

M Compose Message

R toggle Radiorange Map on/off

S Screenshot bpm (win), png (linux)

W Rain map (use topo or dark map)

+ *Next you will zoom to your QTH as far as you can, 100% **identifying** your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home **with the cursor**. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.

*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

Zeile 52:

austria.aprs2.net (APRS IS connection via Internet)

+ *You also need to enter a valid APRS PASSCODE to transmit packets to the **APR S** network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.

+ *Last but not least you have to activate CONNECT SERVER to get data from **an to t he APRS** network.

===Shortcuts===

+ **<nowiki>:</nowiki>** delete markers

@ reset <On Next Click> to menu mode

a Animate (Click to Map to set Parameters)

Zeile 84:

M Compose Message

R toggle Radiorange Map on/off

+ **T toggle Timestamp**

S Screenshot bpm (win), png (linux)

W Rain map (use topo or dark map)


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	11
2 Installation	11
3 Operation manual and help	11
3.1 Shortcuts	12
4 Download	13
5 Further operation manual	13

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
 aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
 austria.aprs2.net (APRS IS connection via Internet)

- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```

```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come

DXL - APRSmap englisch: Unterschied zwischen den Versionen

[Versionsgeschichte interaktiv durchsuchen](#)

[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)


Zeile 34:	Zeile 34:
<div></div>	<div></div>
<div></div>	<div></div>
- ==First steps==	+ ==Operation manual and help==
	[[DXL - APRSmap operating >> Operating instructions]] - the help in handling the program
	+
	+
	+
<div>[[Datei:Aprsmap-1st-start.jpg]]</div>	<div>[[Datei:Aprsmap-1st-start.jpg]]</div>
<div></div>	<div></div>
<div>On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.</div>	<div>On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.</div>
<div></div>	<div></div>
- *First of all you put in your callsign with optinal SSID	+ *First of all you put in your callsign (MY CALLSIGN) with optional SSID
- *Second step is to choose your desired APRS icon	+ *Second step is to choose your desired APRS icon (MY SYMBOL)

<p>- *Next you will zoom to your QTH as far as you can 100% identify your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.</p>	<p>+ *Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.</p>
<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>	<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>
<p>Zeile 48:</p>	<p>Zeile 52:</p>
<p>austria.aprs2.net (APRS IS connection via Internet)</p>	<p>austria.aprs2.net (APRS IS connection via Internet)</p>
<p>- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS IS PASSCODE to find a possibility on getting your code.</p>	<p>+ *You also need to enter a valid APRS PASSCODE to transmit packets to the APR S network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.</p>
<p>- *Last but not least you have to activate CONNECT SERVER to get data from the network.</p>	<p>+ *Last but not least you have to activate CONNECT SERVER to get data from an to t he APRS network.</p>
<p>===Shortcuts===</p>	<p>===Shortcuts===</p>
<p>- : delete markers</p>	<p>+ <nowiki>:</nowiki> delete markers</p>
<p>@ reset <On Next Click> to menu mode</p>	<p>@ reset <On Next Click> to menu mode</p>
<p>a Animate (Click to Map to set Parameters)</p>	<p>a Animate (Click to Map to set Parameters)</p>
<p>Zeile 80:</p>	<p>Zeile 84:</p>
<p>M Compose Message</p>	<p>M Compose Message</p>
<p>R toggle Radiorange Map on/off</p>	<p>R toggle Radiorange Map on/off</p>
	<p>+ T toggle Timestamp</p>
<p>S Screenshot bpm (win), png (linux)</p>	<p>S Screenshot bpm (win), png (linux)</p>
<p>W Rain map (use topo or dark map)</p>	<p>W Rain map (use topo or dark map)</p>


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	17
2 Installation	17
3 Operation manual and help	17
3.1 Shortcuts	18
4 Download	19
5 Further operation manual	19

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
 aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
 austria.aprs2.net (APRS IS connection via Internet)

- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```

```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come

DXL - APRSmap englisch: Unterschied zwischen den Versionen

[Versionsgeschichte interaktiv durchsuchen](#)

[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)

Zeile 34:

- **==First steps==**

Zeile 34:

+ **==Operation manual and help==**

+ **[[DXL - APRSmap operating|>> Operating instructions]] - the help in handling the program**

+

+

+

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- ***First of all you put in your callsign with optional SSID**

+ ***First of all you put in your callsign **(MY CALLSIGN)** with optional SSID**

- ***Second step is to choose your desired APRS icon**

+ ***Second step is to choose your desired APRS icon **(MY SYMBOL)****

<p>- *Next you will zoom to your QTH as far as you can 100% identify your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.</p>	<p>+ *Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.</p>
<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>	<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>
<p>Zeile 48:</p>	<p>Zeile 52:</p>
<p>austria.aprs2.net (APRS IS connection via Internet)</p>	<p>austria.aprs2.net (APRS IS connection via Internet)</p>
<p>- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS IS PASSCODE to find a possibility on getting your code.</p>	<p>+ *You also need to enter a valid APRS PASSCODE to transmit packets to the APR S network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.</p>
<p>- *Last but not least you have to activate CONNECT SERVER to get data from the network.</p>	<p>+ *Last but not least you have to activate CONNECT SERVER to get data from an to t he APRS network.</p>
<p>===Shortcuts===</p>	<p>===Shortcuts===</p>
<p>- : delete markers</p>	<p>+ <nowiki>:</nowiki> delete markers</p>
<p>@ reset <On Next Click> to menu mode</p>	<p>@ reset <On Next Click> to menu mode</p>
<p>a Animate (Click to Map to set Parameters)</p>	<p>a Animate (Click to Map to set Parameters)</p>
<p>Zeile 80:</p>	<p>Zeile 84:</p>
<p>M Compose Message</p>	<p>M Compose Message</p>
<p>R toggle Radiorange Map on/off</p>	<p>R toggle Radiorange Map on/off</p>
	<p>+ T toggle Timestamp</p>
<p>S Screenshot bpm (win), png (linux)</p>	<p>S Screenshot bpm (win), png (linux)</p>
<p>W Rain map (use topo or dark map)</p>	<p>W Rain map (use topo or dark map)</p>


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	23
2 Installation	23
3 Operation manual and help	23
3.1 Shortcuts	24
4 Download	25
5 Further operation manual	25

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
 aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
 austria.aprs2.net (APRS IS connection via Internet)

- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```



```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come

DXL - APRSmap englisch: Unterschied zwischen den Versionen

[Versionsgeschichte interaktiv durchsuchen](#)

[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)

Zeile 34:

- **==First steps==**

Zeile 34:

+ **==Operation manual and help==**

+ **[[DXL - APRSmap operating|>> Operating instructions]] - the help in handling the program**

+

+

+

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- ***First of all you put in your callsign with optional SSID**

+ ***First of all you put in your callsign **(MY CALLSIGN)** with optional SSID**

- ***Second step is to choose your desired APRS icon**

+ ***Second step is to choose your desired APRS icon **(MY SYMBOL)****

<p>- *Next you will zoom to your QTH as far as you can 100% identify your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.</p>	<p>+ *Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.</p>
<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>	<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>
<p>Zeile 48:</p>	<p>Zeile 52:</p>
<p>austria.aprs2.net (APRS IS connection via Internet)</p>	<p>austria.aprs2.net (APRS IS connection via Internet)</p>
<p>- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS IS PASSCODE to find a possibility on getting your code.</p>	<p>+ *You also need to enter a valid APRS PASSCODE to transmit packets to the APR S network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.</p>
<p>- *Last but not least you have to activate CONNECT SERVER to get data from the network.</p>	<p>+ *Last but not least you have to activate CONNECT SERVER to get data from an to t he APRS network.</p>
<p>===Shortcuts===</p>	<p>===Shortcuts===</p>
<p>- : delete markers</p>	<p>+ <nowiki>:</nowiki> delete markers</p>
<p>@ reset <On Next Click> to menu mode</p>	<p>@ reset <On Next Click> to menu mode</p>
<p>a Animate (Click to Map to set Parameters)</p>	<p>a Animate (Click to Map to set Parameters)</p>
<p>Zeile 80:</p>	<p>Zeile 84:</p>
<p>M Compose Message</p>	<p>M Compose Message</p>
<p>R toggle Radiorange Map on/off</p>	<p>R toggle Radiorange Map on/off</p>
	<p>+ T toggle Timestamp</p>
<p>S Screenshot bpm (win), png (linux)</p>	<p>S Screenshot bpm (win), png (linux)</p>
<p>W Rain map (use topo or dark map)</p>	<p>W Rain map (use topo or dark map)</p>


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	29
2 Installation	29
3 Operation manual and help	29
3.1 Shortcuts	30
4 Download	31
5 Further operation manual	31

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
 aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
 austria.aprs2.net (APRS IS connection via Internet)

- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```

```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come

DXL - APRSmap englisch: Unterschied zwischen den Versionen

[Versionsgeschichte interaktiv durchsuchen](#)

[Visuell Wikitext](#)

Version vom 9. April 2021, 09:00 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

Markierung: 2017-Quelltext-Bearbeitung

[← Zum vorherigen Versionsunterschied](#)

Aktuelle Version vom 14. August 2021, 14:53 Uhr (Quelltext anzeigen)

OE2WAO ([Diskussion](#) | [Beiträge](#))

K

Markierung: [Visuelle Bearbeitung](#)

(5 dazwischenliegende Versionen desselben Benutzers werden nicht angezeigt)


Zeile 34:	Zeile 34:
<div></div>	<div></div>
<div></div>	<div></div>
- ==First steps==	+ ==Operation manual and help==
	+ [[DXL - APRSmap operating >> Operating instructions]] - the help in handling the program
	+ <div></div>
	+ <div></div>
	+ <div></div>
<div>[[Datei:Aprsmap-1st-start.jpg]]</div>	<div>[[Datei:Aprsmap-1st-start.jpg]]</div>
<div></div>	<div></div>
<div>On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.</div>	<div>On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.</div>
<div></div>	<div></div>
- *First of all you put in your callsign with optional SSID	+ *First of all you put in your callsign (MY CALLSIGN) with optional SSID
- *Second step is to choose your desired APRS icon	+ *Second step is to choose your desired APRS icon (MY SYMBOL)

<p>- *Next you will zoom to your QTH as far as you can 100% identify your home (zoom level <16). Then open ONLINE - MY POSITION and point to your home. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field, just click OK to save them.</p>	<p>+ *Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.</p>
<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>	<p>*Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.</p>
<p></p>	<p></p>
<p>Zeile 48:</p>	<p>Zeile 52:</p>
<p>austria.aprs2.net (APRS IS connection via Internet)</p>	<p>austria.aprs2.net (APRS IS connection via Internet)</p>
<p></p>	<p></p>
<p>- *You also need to enter a valid APRS PASSCODE to transmit packets to the network (not needed in case of only RX). Just do a internet search on APRS IS PASSCODE to find a possibility on getting your code.</p>	<p>+ *You also need to enter a valid APRS PASSCODE to transmit packets to the APR S network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.</p>
<p>- *Last but not least you have to activate CONNECT SERVER to get data from the network.</p>	<p>+ *Last but not least you have to activate CONNECT SERVER to get data from an to t he APRS network.</p>
<p></p>	<p></p>
<p>===Shortcuts===</p>	<p>===Shortcuts===</p>
<p>- : delete markers</p>	<p>+ <nowiki>:</nowiki> delete markers</p>
<p>@ reset <On Next Click> to menu mode</p>	<p>@ reset <On Next Click> to menu mode</p>
<p>a Animate (Click to Map to set Parameters)</p>	<p>a Animate (Click to Map to set Parameters)</p>
<p>Zeile 80:</p>	<p>Zeile 84:</p>
<p>M Compose Message</p>	<p>M Compose Message</p>
<p>R toggle Radiorange Map on/off</p>	<p>R toggle Radiorange Map on/off</p>
<p></p>	<p>+ T toggle Timestamp</p>
<p>S Screenshot bpm (win), png (linux)</p>	<p>S Screenshot bpm (win), png (linux)</p>
<p>W Rain map (use topo or dark map)</p>	<p>W Rain map (use topo or dark map)</p>


Aktuelle Version vom 14. August 2021, 14:53 Uhr



Für die deutsche Version dieses Projekts [>>>hier klicken<<](#)



APRSmap is a new APRS client software by OE5DXL, which is based on the [OSM](#) map source. It allows a lot of features in only one program by a good usability. NO installation is required, just put it on a disk and start it!



A lot of documentation work will have to be done soon !!

Inhaltsverzeichnis

1 Features	35
2 Installation	35
3 Operation manual and help	35
3.1 Shortcuts	36
4 Download	37
5 Further operation manual	37

Features

- OpenSource and already compiled for windows and linux
- 100% compliance with the current APRS protocol specifications
- No installation required, just copy and start
- No unnecessary menus, focus is on the representation
- IP-based, out-of-the-box network-ready in HAMNET and Internet
- Operations best controlled via shortcuts
- Local serial connection (TNC) possible - operating as an RF IGATE
- Several MapSources can be used. By default, this is OSM - OpenStreetMap
- Downloading map source on demand
- Track filter for delayed / late / repeated packets "f"
- Radio propagation calculation (since v0.36) "R"
- Animation of tracks with timeline "a"
- Animation of the temperature distribution "w"
- Messaging

Installation

After downloading the program you only have to extract the files into a subfolder of your program files folder, e.g. /APRSmap.

No installation routine is required, just extract and run the aprsmap.exe

Operation manual and help

>> [Operating instructions](#) - the help in handling the program

APRSmap 1st Start

On the first start of the program it is necessary to do some configuration. The most important things you have to adjust are in the ONLINE menu. You best configure all steps from up till down.

- First of all you put in your callsign (MY CALLSIGN) with optional SSID
- Second step is to choose your desired APRS icon (MY SYMBOL)
- Next you will zoom to your QTH as far as you can, 100% identifying your home (zoom level >16). Then open ONLINE - MY POSITION and point to your home with the cursor. While push and hold the SHIFT key click on your home. The coordinates will be copied into the MY POSITION field. Just click OK to save them.
- Now you can set the SERVER URL by just inserting your favorite APRS IS. Click ADD to save this entry.

for example:
 aprs.oe2xzt.ampr.at (APRS IS connection via HAMNET)
 austria.aprs2.net (APRS IS connection via Internet)


- You also need to enter a valid APRS PASSCODE to transmit packets to the APRS network (not needed in case of only RX). Just do a internet search on APRS PASSCODE to find a possibility on getting your code.
- Last but not least you have to activate CONNECT SERVER to get data from an to the APRS network.

Shortcuts

```
: delete markers
@ reset <On Next Click> to menu mode
a Animate (Click to Map to set Parameters)
b or <Backspace> go back in position history
c Center (to last clicked Pixel)
d toggle (missing) map download
e toggle Errors only/All for stepping along a track with <>
f Junk Filter toggle on/off
h Heard (click symbol or text of igate before)
i Internal Status Listing
l toggle Labels on/off
m toggle dimm not moving since 10min
o toggle Objects/Items on/off
p toggle mouse-over Hints
q Quit Program
r toggle Radio tracks on/off
s toggle show only stations with a selected symbol
u toggle tx/rx-Monitor window on/off
w toggle WX stations and Temperature
x set Marker 1 to mouse position
y set Marker 2 and Line to Marker 1
B Open Beacon editor
C Enter Category of POI to be drawn on map
D Digi Config open/close
F Find Call (with wildcards * ?), Locator, Latitude/Longitude
H Altitude Colour Map (if srtm-Data available)
M Compose Message
R toggle Radiorange Map on/off
T toggle Timestamp
S Screenshot bpm (win), png (linux)
W Rain map (use topo or dark map)
< > Step along Beacons/Waypoints of a selected User
( ) Map Brightness +/- 5%
/ zoom to Marker 1-2 Square
\ shortcut list
~ change track colour
+ Zoom in - Zoom out
. zoom to track and show only this (clicked before)
= same as . but with radio tracks
0 show all (and radio tracks off)
1,2,3,4 Zoom/Pan to stored Views
7,8,9 use map type as configured
ESC close menus
```

```
Cursor up/down/left/right  move map, same as click near margin
SHIFT with up/down/left/right/[zoom+]/[zoom-]  in smaller steps
DEL    delete selected (Symbol, Waypoint)
TAB    switch between two Views
ctrl-L  Reset Image and Mouse parameters to default
ctrl-V  Paste
```

Download



[APRSmap Download](#) - For Windows, Linux and ARM (Raspberry Pi)

Further operation manual

more information is up to come